

1. Scope

This document is to be used for field make-up acceptance of the Ares™ IPC Connection.

This procedure shall be used in conjunction with FT-RP-000 General Running Procedure and the latest revision of the Connection Data Sheet (CDS). Where conflicts exist, this connection-specific running procedure and CDS shall govern.

1.1. Product Description

Ares™ IPC Connection:

- Flush
- Conventional Shouldered
- Internal Coating and Seal Ring



Figure 1 – Product Image

1.2. Approvals

Created	Angela Hill – Product Engineer	3/19/2026
Reviewed	Israel Martinez – Quality Director	4/13/2026
Approved	Wesley Ott – Director of Engineering	4/13/2026

1.3. Contents

1. Scope.....1

 1.1. Product Description.....1

 1.2. Approvals.....1

 1.3. Contents2

 1.4. Reference Documents2

2. Connection Running3

 2.1. Seal Ring Installation for Internal Plastic Coating (IPC)3

 2.2. Connection Compatibility4

 2.3. Thread Compound Application.....4

 2.3.1. Approved Compounds4

 2.3.2. Compound Amount4

 2.3.3. Thread Compound Application4

 2.4. Connection Make-Up.....5

 2.4.1. General5

 2.4.2. Ares™ IPC Torque-Turn Plot5

 2.4.3. Make-up Acceptance Criteria6

 2.4.3.1. External Shoulder.....6

 2.4.3.2. Graph Acceptance6

1.4. Reference Documents

Document Number	Document
FT-RP-000	General Running Procedure
FT-FI-001	Fermata Connections Field Visual Inspection and Repair Requirements

Available online: fermata-connections.com/running-procedures/

*Always confirm the most current Running Procedure through the online portal or by contacting Field Service.

2. Connection Running

For general running see FT-RP-000 General Running Procedure

Fermata® strongly recommends using a Fermata® certified thread representative for all casing runs. If not used, the operator is responsible for ensuring all make-ups meet Fermata® criteria.

See Section 4.1 in the FT-RP-000 General Running Procedure for Field Service details.

2.1. Seal Ring Installation for Internal Plastic Coating (IPC)

- Confirm that seal rings match the specified Ares™ IPC configuration. Maintain spare seal rings to account for potential damage or loss.
- Allow seal rings and pipe to reach the same ambient temperature prior to installation.
- Inspect all seal rings for damage or defects. Do not install damaged or defective rings.
- Using a new seal ring, compress it by hand and install it into the box end of the connection. Avoid over compression, as excessive distortion may prevent proper seating.
- Install the seal ring with the lip facing the open end of the box connection. Ares™ IPC seal rings are directional; refer to Figure 4 for correct orientation.
- Seat the seal ring by applying uniform pressure around its circumference. A non-metallic tool may be used if necessary.



Figure 2 – Example of PTFE Seal Ring



Figure 3 – Example Distorted Seal Ring



Figure 4 – Directional Seal Ring Installation Diagram

2.2. Connection Compatibility

Ares™ IPC does NOT have compatibility with differing weights within the same OD.

2.3. Thread Compound Application

See FT-RP-000 General Running Procedure Section 4.2 for thread compound application.

2.3.1. Approved Compounds

- Fermata® Constrictor® Advanced Thread Sealant.

2.3.2. Compound Amount

Refer to Table 1 for the required thread compound volume:

Table 1: Thread Compound Amount

OD (inches)	Volume (mL)
2.875	1.0
4.000	2.5
4.500	3.0
5.500	4.5

2.3.3. Thread Compound Application

- Apply thread compound only on the pin connection.
- Coat full thread form (flanks, roots, and crests).




Figure 5 – Thread Form

See Figure 6 and Figure 7 for visual reference.



Figure 6 – Pin Connection Application



Figure 7 – Box Connection (no compound)

2.4. Connection Make-Up

2.4.1. General

See FT-RP-000 General Running Procedure

2.4.2. Ares™ IPC Torque-Turn Plot

- Verify the make-up result against Figure 8.
- For Ares™, shoulder torque occurs when the pin nose contacts the box shoulder. This event appears as a distinct spike on the torque-turn plot and should occur between 5% and 80% of final make-up torque.




Figure 8 – Ares™ IPC Torque-Turn Signature

2.4.3. Make-up Acceptance Criteria


Connections are accepted based on required graph elements (2.4.2), and external shoulder fully seated.

2.4.3.1. External Shoulder


- Verify connection make-up can be made by checking that the external shoulder on the pin is fully seated by the box face.
- No gap allowed.

2.4.3.2. Graph Acceptance


- Figure 8 shows an example of an acceptable make-up signature.
- Figure 9 shows examples of unacceptable make-up graphs.
- Contact Fermata® Support for any graph irregularity's acceptance.
- See FT-RP-000 General Running Procedure for further examples.



NOTE: High shoulder – Break-out, inspect, and remake to max torque.
(a)



NOTE: Irregular torque build just before the optimum torque is reached. Break-out, inspect the connection, and remake with less thread compound.
(b)



NOTE: Yielding – Break-out, lay down pin and box joint, set aside for inspection.
(c)

Figure 9 – Examples (a), (b) and (c) of unacceptable make-up graphs.

Contact Information:

Technical Support: (281) 941-5257, support@fermata-connections.com

Field Services 24/7 Operations: (855) 322-7104