

1. Scope

This document is to be used for field make-up acceptance of the Hercules® SL Connection.

This procedure shall be used in conjunction with FT-RP-000 General Running Procedure and the latest revision of the Connection Data Sheet (CDS). Where conflicts exist, this connection-specific running procedure and CDS shall govern.

1.1. Product Description

Hercules® SL Connection:

- Threaded and Coupled
- Conventional Shouldered
- Thread sealing



Figure 1 – Product Image

1.2. Approvals

Created	Angela Hill – Product Engineer	3/24/2026
Reviewed	Israel Martinez – Quality Director	4/23/2026
Approved	Wesley Ott – Director of Engineering	4/23/2026

1.3. Contents

1. Scope.....1

 1.1. Product Description.....1

 1.2. Approvals.....1

 1.3. Contents2

 1.4. Reference Documents2

2. Connection Running3

 2.1. Connection Compatibility3

 2.2. Thread Compound Application.....3

 2.2.1. Approved Compounds3

 2.2.2. Compound Amount3

 2.2.3. Thread Compound Application3

 2.3. Connection Make-Up.....4

 2.3.1. General4

 2.3.2. Hercules® SL Torque-Turn Plot.....5

 2.3.3. Make-up Acceptance Criteria5

 2.3.3.1. Make-up Indicator5

 2.3.3.2. Graph Acceptance6

1.4. Reference Documents

Document Number	Document
FT-RP-000	General Running Procedure
FT-FI-001	Fermata Connections Field Visual Inspection and Repair Requirements

Available online: fermata-connections.com/running-procedures/

*Always confirm the most current Running Procedure through the online portal or by contacting Field Service.

2. Connection Running

For general running see FT-RP-000 General Running Procedure

Fermata® strongly recommends using a Fermata® certified thread representative for all casing runs. If not used, the operator is responsible for ensuring all make-ups meet Fermata® criteria.

See Section 4.1 in the FT-RP-000 General Running Procedure for Field Service details.

2.1. Connection Compatibility

Hercules® SL does **NOT** have compatibility with differing weights within the same OD.

2.2. Thread Compound Application

See FT-RP-000 General Running Procedure Section 4.2 for thread compound application.

2.2.1. Approved Compounds

- BOL 72733 or API Modified.

2.2.2. Compound Amount

Refer to Table 1 for the required thread compound volume:

Table 1: Thread Compound Amount

OD (inches)	Volume (mL)
5.000	5.0
5.500	5.0
7.625	7.0
8.625	8.0

2.2.3. Thread Compound Application

- Apply thread compound only on the pin connection.
- Coat full thread form (flanks, roots, and crests).




Figure 2 – Thread Form

See Figure 3 and Figure 4 for visual reference.



Figure 3 – Pin Connection Application




Figure 4 – Box Connection (no compound)

2.3. Connection Make-Up

2.3.1. General

See FT-RP-000 General Running Procedure

2.3.2. First Article Make-up

Hercules® SL requires First Article Make-Up, see FT-RP-000 General Running Procedure Section 4.4.3 for the detailed process.

2.3.3. Hercules® SL Torque-Turn Plot

- Verify the make-up result against Figure 5.
- For Hercules® SL, shoulder torque occurs when the pin noses contact. This event appears as a distinct spike on the torque-turn plot and should occur between 5% and 90% of final make-up torque.




Figure 5 – Hercules® SL Torque-Turn Signature

2.3.4. Make-up Acceptance Criteria

Connections are accepted based on required graph elements (2.3.3), and Knurling/Triangle stamp make-up indicators.

2.3.4.1. Make-up Indicator


Verification of connection make-up can be made by checking the triangle stamp or knurling.

Triangle:

- To locate the triangle there is a 1” wide X 24” long white paint stripe is applied to the field end pin.
- After make-up, the box face must be within a tolerance of ± 0.063 ” from the triangle base.


Knurl:

- The knurl is applied around the circumference of the pin.
- After make-up, locate a region around the circumference that has full knurl width indented. The box face must be within a tolerance of ± 0.063 " from the knurl base.




2.3.4.2. Graph Acceptance

- Figure 5 shows an example of an acceptable make-up signature.
- Figure 7 shows examples of unacceptable make-up graphs.
- Contact Fermata® Support for any graph irregularity's acceptance.
- See FT-RP-000 General Running Procedure for further examples.




NOTE: High shoulder – Break-out, inspect, if ok remake to max torque.

(a)



NOTE: Irregular torque build after shoulder and just before the optimum torque is reached. Break-out, inspect the connection. If ok, remake with less thread compound.

(b)



NOTE: Yielding – Break-out, lay down pin and box joint, set aside for inspection.
(c)

Figure 7 – Examples (a), (b) and (c) of unacceptable make-up graphs.

Contact Information:

Technical Support: (281) 941-5257, support@fermata-connections.com

Field Services 24/7 Operations: (855) 322-7104